Environmental Protection Agency

Calibration and Verification of Digital Barometers Procedure

This procedure is written for the Environmental Protection Agency, National Vehicle and Fuel Emissions Laboratory (NVFEL) internal use. The use of specific brand names by NVFEL in this procedure are for reference only and are not an endorsement of those products. This document may be used for guidance by other laboratories.

NVFEL Reference Number

213C

Implementation Approval

Original Procedure Authorized by EPCN #168 on 08-11-94

Revision Description

(1) 09-30-94 The purpose of this change is to revise the procedure as described in EPCN #170.

Table of Contents

1.	Purpose 3	
2.	Test Article Description	
3.	References	
4.	Required Equipment	
5.	Precautions	
6.	Visual Inspection	
7.	Test Article Preparation	
8.	Test Procedure 4	
	100 Calibration	
	200 Verification	
9.	Data Input6	
10.	Data Analysis6	
11.	Data Output	
12.	Acceptance Criteria	
13.	Quality Provisions	
	Attachments	
Attachment A, Ba	rometer Test Unit Diagram	8
Attachment B, Fo	rm 213-01, Digital Barometer Calibration Sheet	9
Attachment C, Fo	rm 213-02, Digital Barometer Verification Sheet	10

1. Purpose

This procedure describes the calibration and verification of Bell and Howell and Mensor digital barometers.

2. Test Article Description

The Bell and Howell and Mensor digital barometers measure atmospheric pressure and provide a digital display on the front panel in inches of mercury. The output of the digital barometer used by Vehicle Testing (VT) is wired to the Laboratory Computer System (LCS).

3. References

- 3.1 Bell and Howell Digital Barometer Instruction Manual (located in the Electronics Shop Office)
- 3.2 Mensor Digital Barometer Operation and Maintenance Manual (located in the Electronics Shop Office)
- 3.3 Princo Standard Mercurial Barometer Instructions and Correction Tables (located in the Gas Blending Lab)
- 3.4 Barometer Test Unit Diagram, see Attachment A

4. Required Equipment

- 4.1 Princo Standard Mercurial Barometer (located in the Gas Blending Lab)
- 4.2 Barometer Test Unit
- 4.3 Form 213-01, Digital Barometer Calibration Sheet, see Attachment B
- 4.4 Form 213-02, Digital Barometer Verification Sheet, see Attachment C

5. Precautions

Avoid removing the digital barometer case unless it becomes necessary to perform troubleshooting and/or corrective maintenance.

6. Visual Inspection

Visually check all plumbing connections, electrical connections, and the digital display for abnormal conditions before proceeding with any calibration or verification procedure. Ensure that the digital barometer sensor inlet is free of obstructions.

7. Test Article Preparation

Place the barometer test unit close to the barometer so fitting F1 (see Figure 1) can be connected to the input pressure fitting of the barometer. Ensure that the water level on both sides of the manometer "U" tube reads zero.

8. Test Procedure

This procedure consists of two parts which may be performed in sequence or separately:

100 Calibration

Performed monthly or after maintenance and repair work.

- Verify that the barometer power has been on for a minimum of 1 hour.
- Read the Princo standard mercurial barometer, located in the Gas Blending Lab, to the nearest 0.01 inch of mercury. Apply temperature and gravity correction factors as defined on Form 213-01.

Record these data as "PB" on Form 213-01.

103 Verify that the digital barometer agrees within 0.03 inch of mercury of the corrected mercury column reading.

If the reading does not agree, recheck the Princo mercurial barometer reading and ensure that the inlet fitting of the digital barometer is free of obstructions.

If the reading still does not agree, Electronics Shop personnel should remove the unit from the case and adjust the span and zero pots to correct the reading. Consult the appropriate digital barometer instruction manual for additional information on these adjustments.

104 Refer to the diagram of the barometer test unit while performing Steps 104 through 124 of the calibration (see Attachment A, Figure 1). Place shut-off valves V1 and V2 of the barometer test unit in the open position.

213C	Calibration and Verification Page 5 of 10 of Digital Barometers Procedure								
105	Connect fitting F1 of the barometer test unit to the digital barometer input pressure fitting.								
106	The manometer should read zero and the digital barometer should read atmospheric pressure.								
	If they do not, check the positions of valves V1 and V2.								
107	Record the digital barometer reading as "PA" on Form 213-01.								
108	Pull the syringe plunger out 4 inches.								
109	Turn valve V1 to the closed position.								
110	Slowly push the syringe plunger in until the manometer reads approximately 18 inches of H_2O (±2 inches).								
111	Turn valve V2 to the closed position.								
112	Record the reading of the digital barometer as "P1" in the +•P column of Form 213-01.								
113	Record the reading of the manometer as "P2" in the +•P column of Form 213-01.								
114	Turn valve V2 to the open position.								
115	Turn valve V1 to the open position.								
116	The manometer should read zero and the digital barometer should read atmospheric pressure.								
	If they do not, check positions of valves V1 and V2.								
117	Push the syringe plunger all the way in.								
118	Turn valve V1 to the closed position.								
119	Slowly pull the syringe plunger out until the manometer reads approximately 18 inches of H_2O (\pm 2 inches).								
120	Turn valve V2 to the closed position.								

- Record the reading of the digital barometer as "P1" in the -•P column of Form 213-01.
- Record the reading of the manometer as "P2" in the -•P column of Form 213-01.
- Perform the calculations shown on Form 213-01 for the +•P and -•P tests. The difference between the digital barometer reading and the calculated absolute pressure must be less than or equal to 0.03 inches of mercury.

If it is not, corrective action must be initiated before the unit can be used for testing.

Disconnect fitting F1 of the barometer test unit from the digital barometer.

200 Verification

Performed weekly.

Perform Steps 101 and 102 of the calibration procedure. The digital barometer must agree within 0.05 inch of mercury of the corrected mercury column (PB). Record the data on Form 213-02.

If the instrument is out of tolerance, perform the complete calibration procedure, Steps 101 through 124.

Compare the digital barometer reading and the Laboratory Computer System reading for each VT test site.

If the readings at any site differ by more than 0.01 inch of mercury, notify Computer Group personnel.

9. Data Input

All data and calculations are documented on Form 213-01 or 213-02.

10. Data Analysis

Calculations indicated on Forms 213-01 and 213-02 are performed by the technician.

11. Data Output

The team leader reviews Forms 213-01 and 213-02 to assure complete documentation and accuracy.

12. Acceptance Criteria


The digital barometer must read within 0.03 inch of mercury of the absolute pressure in a range of 27-31 inches of mercury for the calibration and within 0.05 inch of mercury of the corrected mercury column (PB) for the verification.

13. Quality Provisions

- 13.1 The log sheet used for recording the data is signed and dated by the technician performing the calibration or verification.
- 13.2 Comments that describe any problem diagnosed or maintenance performed are included on Form 213-01 or 213-02.
- 13.3 The C&M Manager initials the log sheet after reviewing it and initiates corrective action when necessary.
- 13.4 The technician performing the calibration or verification ensures that the barometer case is kept free of dirt and dust.

Attachment A

BAROMETER TEST UNIT



V =VALVE F = FITTING

Figure 1

DIGITAL BAROMETER CALIBRATION SHEET

FORM 213-01: 08-11-94

Calibration and Verification of Digital Barometers Procedure

Attachment B

BOX DENOTES WHICH STEP OF TEST PROCEDURE TO PERFORM. ING = "HG 102 WINUS]= "HG 102 PA= "HG 108 - A P "HG 122 "HG 122		Ç
BOX DENOTES WHICH STEP PROCEDURE TO PERFORM. ING = "HG PA= "HG = "'HG		
OBSERVED BARO READING = CORRECTION FACTOR (MINUS)= CORRECTED BARO PB= DIGITAL BARO READING PA= DIFFERENCE (PB-PA) =		(
82 82 82 82 82 82 82 82 82 82 82 82 82 8		
PBOP. ID. TECH. TE	TESSURE	
28 TABLI 16, LAT.= 0.132 (0.132 (0.132 (0.133 (0.13	"HG" '2] SLUTE PF	
#BE	7369 X F TEABSC	+ P3
4TE ST. SER# ST. SER# SOM# =900FT, AVG. BAB.=29.00°HG, LA =900FT, AVG. BAB.=29.00°HG, LA 68 70 72 74 76 0.111 0.117 0.122 0.127 0.13 DIGITAL BAROMETER U - TUBE MANOMETER READING	CONVERT P2 TO "HG P3 = (0.07369 X P2) CALCULATE ABSOLUT	CALCULATE ABSOLUTE PRESSURE P4 = PB + P3
DATE INST. SER# BAPOM# BAROMETER CORRECTION FACTOR TABLE ALT.=900FT, AVG. BAR.=29.00"HG, LAT.=42.3 ° N TEMP. 68 70 72 74 76 78 DATA DATA DATA DATA DATA DESCRIPTION DATA	P 2	·

ACCEPTANCE TO LERANCE: DIFFERENCE OF PIAND P4 MUST BE LESS THAN OR EQUAL TO 0.03" HG.

뜻

뜻

P1 - P4

4

Attachment C

DIGITAL BAROMETER VERIFICATION SHEET

TECH								_	_	STEP O	F TES
TEAM LDR. IN	11					— PF	ROCEDI	JRE TO	PERFO	ORM.	
		BARON	<u>METER</u>	CORRE	CTION	FACTO	R TABI	<u>.E</u>			
ALT.=900FT, AVG. BAR.=29.00"HG, LAT.=42.3 ♭ N											
	TEMP.	68	70	72	74	76	78	80	82		
	CF	0.111	0.117	0.122	0.127	0.132	0.137	0.143	0.148		
			•							I	
			BARO READING ="HG 102								
	CORRE	CTION	FACTO	R (MIN	US)=			_ "HG	•	_	
	CORRE	CIEDI	SARU		PB = _			ਜਫ	ļ		
INST. SER#_										Г	201
ROOM#			D	IFFERE	ENCE (PB-PA)		=		"HG	Ī
INST. SER#_			D	IGITAL	BARO F	READIN	G PA	=		"HG	V
ROOM#											
INST. SER#_											
ROOM#			D	IFFERE	ENCE (PB-PA)		=		"HG	
INST. SER#_			D	IGITAL	BARO F	READIN					
ROOM#			D	IFFERE	ENCE (PB-PA)		=		"HG	
INST. SER#_											
ROOM#			D	IFFERE	ENCE (PB-PA)		=		"HG	
INST. SER#_											
ROOM#			D	IFFERE	ENCE (PB-PA)		=		"HG	
INST. SER#_			D	IGITAL	BARO F	READIN	G PA	=		"HG	
ROOM#											
INST. SER#_			D	IGITAL	BARO F	READIN	G PA	=		"HG	
ROOM#											
INST. SER#_ ROOM#			Г	IFFERE	NCE (PR-PA)		_		"HG	
INST. SER#_						-					
ROOM#_			D	IOIIAL	DAI(O I	(LADIIN	O IA			_ 110	
COMPARISON	OF LA	RGE SC	OAK DIC	SITAL B	AROME	TER TO	LCS F	RINTO	<u>U</u> T	202	
LARGE SOAK	DIGITA	BARC	METER	PEAD	ING			"HG			
BARO READI					-	•		HG DI	FF		_"HG
BARO READI								HG DI			_ "HG
BARO READI	NG FRC	M SITE	A003 L	.CS PRI	INTOUT		"	HG DI	FF		_"HG
ACCEPTANCE	TOLER	ANCES	: DIFF	ERENC	E OF PI	B AND F	PA MUS	ST BE L	ESS TH	IAN OR	
								-	ST BE V		
			0.01"	HG OF	LARGE	SOAK	DIGITA	L BARC	METER	READI	NG.
COMMENTS											

FORM 213-02: 08-11-94